ATTACHMENTS, ACCESSORIES AND REPLACEMENT PARTS

NAME OF PART	Part Number
Needles (Pkg. of 12 assorted sizes)	2270
Needles (Pkg. of 24 assorted sizes)	2271
Oil	W1049
Tension Spring	1072
Bobbin (Pkg. of 6)	1557
Bobbin case complete	1550
Bobbin case tension spring	1554
Bobbin case tension spring screw	S551
Bobbin case cover plate, hinged	1251
Bobbin winder rubber ring	6352
Check spring (Thread take-up)	4060
Electric cord and block for Portable	107
Electric cord and block for Cabinet	109
Electric foot control for Portable	106
Electric knee control for Cabinet	110
Hemmer Foot (Narrow Hemmer)	A15
Motor Brush	155
Motor Brush Spring	156
Motor Brush Spring cap	157
Motor V Belt	282
Motor Pulley for V Belt	228
Needle clamp	1203
Needle clamp thumb screw	S201
Needle plate	4250
Presser foot—Zigzag	3156
Presser foot for buttons	3901
Presser foot for buttonholes	4190

NAME OF PART	Part Number
Darning Foot	4195
Zipper and Cording Foot	4194
Binder	4196
Presser foot screw	S153
Sewing light bulb	292
Spool pin	6406
Pattern Cam No. 1	292-1
Pattern Cam No. 2	292-2
Pattern Cam No. 3	292-3
Pattern Cam No. 4	292-4
Pattern Cam No. 5	292-5
Pattern Cam No. 6	292-6
Pattern Cam No. 7	292-7
Pattern Cam No. 8	292-8
Pattern Cam No. 9	292-9
Pattern Cam No. 10	292-10
Pattern Cam No. 11	292-11
Pattern Cam No. 12	292-12
Pattern Cam BH	292-BH
Pattern Cam BS	292-BS
Ruffler	A1
Tucker	A2
Hemmer 3/16"*	A3
Hemmer 1/4"*	A4
Hemmer 3/8"*	A5
Hemmer 5/8"*	A6
* Attachment Foot (Required to Assemble Above to Machine)	A12
Shirrer	A13

Order attachments, accessories or replacement parts from your nearest Ward Retail Store, Mail Order House or Catalog Store. If requested, prices will be quoted in advance. To have your order filled promptly and correctly, please furnish the model and serial number as it appears on the nameplate.